

LABORATORY DEPARTMENT

MODEL TYPE: 1118-18

Procedure for stacking Duo boxes

This procedure demonstrates how to stack two (1118-18) boxes in order to obtain one 1118-36. This procedure works on all sizes.

1. If the boxes are provided with hardware, you first need to completely remove the hardware from the box on the bottom.



2. Then take the top box and drill one hole on each of the ribs under the hardware at 3" from the bottom.



3. Insert the L-shaped supports and bolt the smaller part with the top box.



4. Stack the boxes and insert the L-shaped supports through the holes which were intended for the hardware and bolt them to attach the two boxes.



Result :

